






Cross Wire Parallel Motion



















With the wire adjuster positioned centrally, attach the straight edge in the middle of the board using the spring tab assembly to secure it to the wire.





The amount of flex in the spring tab can be adjusted to achieve the desired amount of resistance.